


## Spa Vacuum





The Spa Vacuum is ideal for spas and hot tubs of every size and surface. It is completely independent of your spa's filtration system and fully self-contained as well. Cleaning is easy — just press a button and the quiet and efficient simple pump action creates suction that draws in water, dirt, and debris from pool or spas. The dirt and debris get trapped inside the filter basket as the water flows out. This hand held vacuum cleaner is easy to install and maneuver. You don't have to worry about additional hoses, cords, or external pumps that would normally need to attach to your filtration system. Equipped with its very own spa pole, the Spa Vac can expand up to approximately 5 feet in length if you need to access very hard to reach areas. The on-board debris catcher comes with a reusable filter so you don't have to spend extra money purchasing more filter bags once they become full. This user friendly spa vacuum is battery powered and take 8 AA batteries (included). Using The Spa Vac cleaner will give you more time to relax and enjoy your hot tub, as opposed to spending extra time cleaning it.

## **Notes**

- 1. Battery compartment is not waterproof. Do not submerge or get wet.
- 2. Clean filter basket after every use
- 3. Vacuum's cleaning end should be under water surface for cleaning
- 4. Lock the compartment after changing the batteries
- 5. Don't force the battery compartment to close. Could destroy electrical wire.
- 6. To clean the walls, install the brush. To clean the floors, remove brush for better suction.
- 7. Don't unscrew 93230-02 Main Body. Don't take apart the pump, warranty will be voided.

## Cleaning filter basket







Twist to adjust length



**Replacing batteries** 





REF	PART	DESCRIPTION
No.	NUMBER	DESCRIPTION
1	93230-08	Handle Cap
2	93230-14	Gasket
3	93230-17	Battery Case
4	93230-06	Handle
5	93230-15	Waterproof Cap
6	93230-20	Switch
7	71516-05	Self Tapping Screws
8	93230-19	Inner AL Pole
9	90695-02	Lock Screw
10	93230-25	Spring Electric Wire
11	90695-03	Screw Fitting
12	93230-18	Outer AL Pole
13	90647-08	Rivet
14	93230-01	AL Union
15	93230-35	Position Block
16	93230-23	Direct Current Motor
17	93230-26	O-Ring
18	93230-04	Motor Cover
19	93230-27	Seal
20	93230-07	Impeller
21	93230-03a	Pump Body
22	93230-02	Main Body
23	93230-09	Filter Net
24	93230-10	Check Valve
25	93230-05	Vacuum Mouth
26	93230-11	Nozzle
27	93230-22	Brush